


2. Electrical Components Location

A: ENGINE


1. MODULE

LHD model



OBD0003E








RHD model




B2M0430H

- ① Engine control module (ECM)
- ② Data link connector (for Subaru select monitor only)
- ③ Data link connector (for Subaru select monitor and OBD-II general scan tool)

- ④ Test mode connector
- ⑤ CHECK ENGINE malfunction indicator lamp (MIL)

LHD model  OBD0004B	RHD model  B2M0431B
LHD model  OBD0005G	RHD model  B2M0432C
LHD model  OBD0006E	RHD model  B2M0433C
 B2M0470A	


2. SENSOR




B2M1169D

- ① Pressure sensor
- ② Mass air flow sensor
- ③ Engine coolant temperature sensor
- ④ Throttle position sensor


- ⑤ Knock sensor
- ⑥ Camshaft position sensor
- ⑦ Crankshaft position sensor




B2M0776A




B2M1034A




B2M1690A




B2M1035A



B2M1691A




OBD0015A




B2M0213B

SUBARU.

2200 cc model


B2M0471A

2500 cc model


B2M0472A

- ⑧ Front oxygen sensor
- ⑨ Rear oxygen sensor (Except 2200 cc California spec. vehicles)

- ⑩ Rear oxygen sensor (2200 cc California spec. vehicles)
- ⑪ Front catalytic converter
- ⑫ Rear catalytic converter




OBD0018A


2200 cc Federal spec. vehicles

OBD0019E


2200 cc California spec. vehicles



B2M0473C




OBD0524C



OBD0525C


SUBARU.

LHD model



OBD0003F


RHD model




B2M0430F

- ① Fuel level sensor
- ② Fuel temperature sensor (2200 cc AWD except Taiwan spec. vehicles)


- ③ Fuel tank pressure sensor (2200 cc AWD except Taiwan spec. vehicles)
- ④ Fuel sub level sensor



B2M0921A




B2M0922A



B2M0946A

SUBARU.


3. SOLENOID VALVE, EMISSION CONTROL SYSTEM PARTS AND IGNITION SYSTEM PARTS




B2M1169E

- ① Pressure sources switching solenoid valve
- ② Idle air control solenoid valve
- ③ EGR valve (Except 2200 cc MT vehicles)
- ④ EGR control solenoid valve (Except 2200 cc MT vehicles)

- ⑤ Purge control solenoid valve
- ⑥ Ignitor
- ⑦ Ignition coil




B2M0777A




B2M1036A

2200 cc model




B2M1037A

2500 cc model




B2M0670B

2200 cc model




B2M1038A


2500 cc model



OBD0024B




B2M1039A




B2M1040A

2200 cc model




B2M1041A

2500 cc model




B6M0160C

LHD model



OBD0003G

RHD model





B2M0430G


⑧ Pressure control solenoid valve (2200 cc AWD except Taiwan spec. vehicles)

⑨ Vent control solenoid valve (2200 cc except AWD Taiwan spec. vehicles)

⑩ Canister (2200 cc AWD except Taiwan spec. vehicles)




LHD model



OBD0003H


RHD model



B2M1042A


① Inhibitor switch (AT vehicles only)	⑥ Radiator main fan relay 2 (With A/C models only)
② Fuel pump	⑦ Radiator sub fan relay 1 (With A/C models)
③ Main relay	Main fan relay (Without A/C models)
④ Fuel pump relay	⑧ Radiator sub fan relay 2 (With A/C models only)
⑤ Radiator main fan relay 1 (With A/C models only)	⑨ Starter

Aluminum body type




OBD0047C

Plastic body type




B2M1043E




B2M0216A

LHD model




B2M0218C


RHD model




B2M0434B




OBD0034A




OBD0036A



OBD0038A

B: TRANSMISSION**1. MODULE****LHD model**

OBD0039B


RHD model

B2M1033A

① Transmission Control Module (TCM) [AT vehicles]


② AT diagnostic indicator light [AT vehicles]

LHD model




B3M0443F

RHD model




B3M0445D



B2M0470B

SUBARU.

2. SENSOR




- ① Vehicle speed sensor 1 [AT FWD vehicles]
- ② Vehicle speed sensor 1 [AT AWD vehicles]
- ③ Vehicle speed sensor 2 [MT vehicles]

- ④ Vehicle speed sensor 2 [AT vehicles]
- ⑤ ATF temperature sensor [AT vehicles]
- ⑥ Brake light switch

3. SOLENOID VALVE AND RELAY


● For AT vehicles




- ① Dropping resistor
- ② Inhibitor switch
- ③ Shift solenoid valve 1
- ④ Shift solenoid valve 2

- ⑤ Shift solenoid valve 3
- ⑥ Duty solenoid valve A
- ⑦ Duty solenoid valve B

● For MT vehicles



① Neutral position switch (FWD models)



② Neutral position switch (AWD models)