


## 6. Security System


### A: ELECTRICAL COMPONENTS LOCATION



B6M0403A


- |                                                                         |                                                                    |
|-------------------------------------------------------------------------|--------------------------------------------------------------------|
| ① Security control module                                               | ⑨ Rear gate switch (WAGON)                                         |
| ② Security indicator light                                              | ⑩ LH door key cylinder lock/unlock switch (built-in tamper switch) |
| ③ RH door key cylinder lock/unlock switch (built-in tamper switch)      | ⑪ Starter interrupt relay                                          |
| ④ Door switch                                                           | ⑫ Headlight alarm relay                                            |
| ⑤ Door lock/unlock switch                                               | ⑬ Ignition switch (ACC position)                                   |
| ⑥ Trunk lid key cylinder unlock switch (SEDAN) (built-in tamper switch) | ⑭ Engine hood switch                                               |
| ⑦ Trunk lid switch (SEDAN)                                              | ⑮ Horn                                                             |
| ⑧ Rear gate key cylinder lock/unlock switch (WAGON)                     | ⑯ Headlight                                                        |

B: SCHEMATIC



B6H0319


## C: CONTROL MODULE I/O SIGNAL





B6M0405

| Content                                              | Terminal No.   | Measuring conditions and I/O signals<br>(Ignition switch ACC position)                                                                                                                                                                                            |
|------------------------------------------------------|----------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Door lock/unlock switch                              | 1<br>(INPUT)   | <ul style="list-style-type: none"> <li>Battery voltage is present when all doors and rear gate (WAGON) are locked.</li> <li>"0" volt is present when one of the doors or rear gate (WAGON) is unlocked.</li> </ul>                                                |
| Key cylinder lock switch                             | 2<br>(INPUT)   | <ul style="list-style-type: none"> <li>"0" volt is present when key cylinder is turned to LOCK position.</li> <li>Battery voltage is present when key cylinder is in positions other than LOCK.</li> </ul>                                                        |
| Tamper switch                                        | 3<br>(INPUT)   | <ul style="list-style-type: none"> <li>Battery voltage is present when key cylinder switch is installed to key cylinder.</li> <li>"0" volt is present when key cylinder switch is removed from key cylinder.</li> </ul>                                           |
| Door switch                                          | 4<br>(INPUT)   | <ul style="list-style-type: none"> <li>Battery voltage is present when all doors are closed.</li> <li>"0" volt is present when one of the doors is open.</li> </ul>                                                                                               |
| Starter interrupt relay                              | 5<br>(OUTPUT)  | <ul style="list-style-type: none"> <li>Battery voltage is present when ignition switch is turned ACC or ON.</li> <li>"0" volt is present when security system is in alarm state.</li> </ul>                                                                       |
| Ignition switch (ACC)                                | 6<br>(INPUT)   | <ul style="list-style-type: none"> <li>Battery voltage is present when ignition switch is turned ACC or ON.</li> <li>"0" volt is present when ignition switch is turned OFF.</li> </ul>                                                                           |
| Security indicator light                             | 7<br>(OUTPUT)  | <ul style="list-style-type: none"> <li>Battery voltage is present when indicator light goes off.</li> <li>"0" volt is present when indicator light illuminates.</li> </ul>                                                                                        |
| Power supply (back-up)                               | 8              | Battery voltage is constantly present.                                                                                                                                                                                                                            |
| Ground                                               | 9              | —                                                                                                                                                                                                                                                                 |
| Engine hood switch                                   | 10<br>(INPUT)  | <ul style="list-style-type: none"> <li>Battery voltage is present when engine hood is closed.</li> <li>"0" volt is present when engine hood is open.</li> </ul>                                                                                                   |
| Trunk lid switch (SEDAN)<br>Rear gate switch (WAGON) | 11<br>(INPUT)  | <ul style="list-style-type: none"> <li>Battery voltage is present when trunk lid or rear gate is closed.</li> <li>"0" volt is present when trunk lid or rear gate is open.</li> </ul>                                                                             |
| Headlight alarm relay                                | 12<br>(OUTPUT) | <ul style="list-style-type: none"> <li>Battery voltage is present when ignition switch is turned ACC or ON.</li> <li>"0" volt and battery voltage repeats in alarm state. (Headlights flash intermittently at 0.2 sec. ON and 0.6 sec. OFF intervals).</li> </ul> |
| Horn relay                                           | 13<br>(OUTPUT) | <ul style="list-style-type: none"> <li>Battery voltage is present when ignition switch is turned ACC or ON.</li> <li>"0" volt and battery voltage repeats in alarm state. (Horn sounds intermittently at 0.2 sec. ON and 0.6 sec. OFF intervals.)</li> </ul>      |
| Key cylinder unlock switch                           | 14<br>(INPUT)  | <ul style="list-style-type: none"> <li>"0" volt is present when key cylinder is turned to UNLOCK position.</li> <li>Battery voltage is present when key cylinder is in positions other than UNLOCK.</li> </ul>                                                    |
| Trunk lid key cylinder unlock switch (SEDAN)         | 15<br>(INPUT)  | <ul style="list-style-type: none"> <li>"0" volt is present when trunk lid key cylinder is turned to UNLOCK position.</li> <li>Battery voltage is present when trunk lid key cylinder is in positions other than UNLOCK.</li> </ul>                                |



## D: BASIC DIAGNOSTICS PROCEDURE








## E: DIAGNOSTICS PROCEDURE FOR SECURITY CONTROL MODULE POWER SUPPLY/GROUND CIRCUIT



### 1. CHECK FUSE AND POWER SUPPLY CIRCUIT.


- 1) Check fuse No. 25.
- 2) Measure voltage between main fuse box connector and body.

**Connector & terminal / Specified voltage:**  
**(F35) No. 2 — Body / 10 V, or more**




- 3) Disconnect connector from security control module.
- 4) Measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**  
**(B93) No. 8 — Body / 10 V, or more**




- 5) Check fuse No. 3.
- 6) Turn ignition switch to ACC.
- 7) Measure voltage between fuse and relay box connector and body.

**Connector & terminal / Specified voltage:**  
**(i5) No. 13 — Body / 10 V, or more**



- 8) Disconnect connector from security control module.
- 9) Measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**  
**(B93) No. 6 — Body / 10 V, or more**





## 2. CHECK GROUND CIRCUIT BETWEEN SECURITY CONTROL MODULE AND BODY.

- 1) Turn ignition switch to OFF.
- 2) Disconnect connector of security control module.
- 3) Measure resistance of harness connector between security control module and body.

**Connector & terminal / Specified resistance:**  
**(B93) No. 9 — Body / 10 Ω, max.**




## F: DIAGNOSTICS PROCEDURE FOR SECURITY INDICATOR LIGHT AND INDICATOR LIGHT CIRCUIT



### 1. CHECK SECURITY INDICATOR LIGHT.

- 1) Remove security indicator light.
- 2) Measure resistance between security indicator light connector terminals.


**Terminals / Specified resistance:**  
**No. 2 — No. 4 / Approx. 120  $\Omega$**



### 2. CHECK POWER SUPPLY FOR INDICATOR LIGHT.

- 1) Disconnect connector of security indicator light.
- 2) Measure voltage between security indicator light connector and body.

**Connector & terminal / Specified voltage:**  
**(i8) No. 2 — Body / 10 V, or more**





### 3. CHECK HARNESS CONNECTOR BETWEEN SECURITY INDICATOR LIGHT AND SECURITY CONTROL MODULE.

- 1) Disconnect connectors of security indicator light and security control module.
- 2) Measure resistance of harness connector between security indicator light and security control module.

**Connector & terminal / Specified resistance:**  
**(i8) No. 4 — (B93) No. 7 / 10  $\Omega$ , max.**

## G: DIAGNOSTICS PROCEDURE FOR DOOR SWITCH SIGNAL



## 1. CHECK DOOR SWITCH INPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Turn door switch ON/OFF and measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**

**(B93) No. 4 — Body / 10 V, or more (Door closed)  
/ 1 V, max. (Door opened)**

NOTE:

When one of the doors is open, the voltage may be 1 V, max.



## 2. CHECK DOOR SWITCH.

Refer to 6-2 [W8B1] for inspection of door switch.

NOTE:

The door switch is used for interior light also.

## H: DIAGNOSTICS PROCEDURE FOR ENGINE HOOD SWITCH SIGNAL



### 1. CHECK ENGINE HOOD SWITCH INPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Turn engine hood switch ON/OFF and measure voltage between security control module connector and body.

#### **Connector & terminal / Specified voltage:**



**(B93) No. 10 — Body / 10 V, or more (Hood closed)**

**/ 1 V, max. (Hood opened)**

### 2. CHECK ENGINE HOOD SWITCH.

Refer to 6-2 [W22B3] for inspection of engine hood switch.

## I: DIAGNOSTICS PROCEDURE FOR TRUNK LID SWITCH (SEDAN) OR REAR GATE SWITCH (WAGON) SIGNAL



### 1. CHECK TRUNK LID SWITCH (SEDAN) OR REAR GATE SWITCH (WAGON) INPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Turn trunk lid switch (or rear gate switch) ON/OFF and measure voltage between security control module connector and body.

#### Connector & terminal / Specified voltage:

**(B93) No. 11 — Body / 10 V, or more  
(Lid or gate closed)  
/ 1 V, max.  
(Lid or gate opened)**



### 2. CHECK TRUNK LID SWITCH (SEDAN) OR REAR GATE SWITCH (WAGON).

Refer to 6-2 [W8B2/W8B3] for inspection of trunk lid switch/rear gate switch.

#### NOTE:

The trunk lid switch/rear gate switch is used for both trunk room light/luggage room light.

## J: DIAGNOSTICS PROCEDURE FOR DOOR LOCK/UNLOCK SWITCH SIGNAL



### 1. CHECK DOOR LOCK/UNLOCK SWITCH INPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Close all the doors and rear gate (WAGON), and lock with ignition key.
- 3) Measure voltage between security control module connector and body.

#### **Connector & terminal / Specified voltage:**

**(B93) No. 1 — Body / 10 V, or more**

#### **NOTE:**

When one of the door (driver, passenger or rear gate) lock knobs is in unlocked position, the voltage may be 1 V, max.

- 4) Unlock the door with ignition key.
- 5) Measure voltage between security control module connector and body.

#### **Connector & terminal / Specified voltage:**

**(B93) No. 1 — Body / 1 V, max.**



### 2. CHECK DOOR LOCK/UNLOCK SWITCH.

Refer to 6-2 [W22B5] for inspection of door lock/unlock switch.

## K: DIAGNOSTICS PROCEDURE FOR KEY CYLINDER LOCK/UNLOCK SWITCH AND TAMPER SWITCH SIGNAL

### NOTE:

Key cylinder lock switch, key cylinder unlock switch and tamper switch are combined as a unit.




### 1. CHECK KEY CYLINDER SWITCH INPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Measure voltage between security control module connector and body while turning each key cylinder with ignition key.



**Doors (RH and LH), and rear gate (WAGON)**

**Connector & terminal / Specified voltage:**

**(B93) No. 2 — Body / 1 V, max. (LOCK position) / 10 V, or more (other than LOCK position)**



**(B93) No. 14 — Body / 1 V, max. (UNLOCK position) / 10 V, or more (other than UNLOCK position)**

**Trunk lid (SEDAN)****Connector & terminal / Specified voltage:****(B93) No. 15 — Body / 1 V, max.****(UNLOCK position)****/ 10 V, or more (other than UNLOCK position)**

3) Measure voltage between security control module connector and body while removing/installing key cylinder switch from/to door outer handle.



**Connector & terminal / Specified voltage:****(B93) No. 3 — Body / 10 V, or more****(Switch is installed.)****/ 1 V, max.****(Switch is removed.)****NOTE:**

For SEDAN vehicles, remove key cylinder switch from trunk lid key cylinder to perform the above inspection.

**2. CHECK KEY CYLINDER SWITCH.**

Refer to 6-2 [W22B4] for inspection of key cylinder lock/unlock switch and tamper switch.

## L: DIAGNOSTICS PROCEDURE FOR STARTER INTERRUPT SIGNAL



### 1. CHECK STARTER INTERRUPT OUTPUT SIGNAL FOR SECURITY CONTROL MODULE.


- 1) Remove security control module without disconnecting connector.
- 2) Measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**  
**(B93) No. 5 — Body / 10 V, or more**

- 3) Set security system in armed state.
- 4) Open the door without ignition key to operate the security system (alarm state).
- 5) Measure voltage between security control module and body during alarm state.

**Connector & terminal / Specified voltage:**  
**(B93) No. 5 — Body / 1 V, max.**






## 2. CHECK POWER SUPPLY FOR STARTER INTERRUPT RELAY.


- 1) Remove starter interrupt relay without disconnecting connector.
- 2) Measure voltage between starter interrupt relay connector and body.

**Connector & terminal / Specified voltage:**  
**(B59) No. 1 — Body / 10 V, or more**



## 3. CHECK CONTINUITY OF STARTER INTERRUPT RELAY.

- 1) Remove starter interrupt relay.
- 2) Check continuity between terminals No. 1 and No. 2 of starter interrupt relay.



## 4. CHECK HARNESS CONNECTOR BETWEEN STARTER INTERRUPT RELAY AND SECURITY CONTROL MODULE.



- 1) Disconnect connectors of starter interrupt relay and security control module.
- 2) Measure resistance of harness connector between starter interrupt relay and security control module.

**Connector & terminal / Specified resistance:**  
**(B59) No. 2 — (B93) No. 5 / 10  $\Omega$ , max.**

## 5. CHECK STARTER INTERRUPT RELAY.

Refer to 6-2 [W22B1] for inspection of starter interrupt relay.

## M: DIAGNOSTICS PROCEDURE FOR HORN ALARM SIGNAL




### 1. CHECK HORN ALARM OUTPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**  
**(B93) No. 13 — Body / 10 V, or more**

- 3) Set security system in armed state.
- 4) Open the door without ignition key to operate the security system (alarm state).
- 5) Measure voltage between security control module and body during alarm state.


**Connector & terminal / Specified voltage:**  
**(B93) No. 13 — Body / repeats 1 V, max. (0.2 sec.) and 10 V, or more (0.6 sec.) intervals**



## 2. CHECK POWER SUPPLY FOR HORN RELAY.


- 1) Check fuse No. 12.
- 2) Remove horn relay without disconnecting connector.
- 3) Measure voltage between horn relay connector and body.

**Connector & terminal / Specified voltage:**  
**(B49) No. 2 — Body / 10 V, or more**



## 3. CHECK CONTINUITY OF HORN RELAY.

- 1) Remove horn relay.
- 2) Check continuity between terminals No. 1 and No. 2 of horn relay.



## 4. CHECK HARNESS CONNECTOR BETWEEN HORN RELAY AND SECURITY CONTROL MODULE.



- 1) Disconnect connectors of horn relay and security control module.
- 2) Measure resistance of harness connector between horn relay and security control module.

**Connector & terminal / Specified resistance:**  
**(B49) No. 1 — (B93) No. 13 / 10  $\Omega$ , max.**

## 5. CHECK HORN RELAY.

Refer to 6-2 [W15B2] for inspection of horn relay.

## N: DIAGNOSTICS PROCEDURE FOR HEADLIGHT ALARM SIGNAL




### 1. CHECK HEADLIGHT ALARM OUTPUT SIGNAL FOR SECURITY CONTROL MODULE.

- 1) Remove security control module without disconnecting connector.
- 2) Measure voltage between security control module connector and body.

**Connector & terminal / Specified voltage:**  
**(B93) No. 12 — Body / 10 V, or more**

- 3) Set security system in armed state.
- 4) Open the door without ignition key to operate the security system (alarm state).
- 5) Measure voltage between security control module and body during alarm state.


**Connector & terminal / Specified voltage:**  
**(B93) No. 12 — Body / repeats 1 V, max. (0.2 sec.) and 10 V, or more (0.6 sec.) intervals**



## 2. CHECK POWER SUPPLY FOR HEADLIGHT ALARM RELAY.


- 1) Remove headlight alarm relay without disconnecting connector.
- 2) Measure voltage between headlight alarm relay connector and body.

**Connector & terminal / Specified voltage:**  
**(B58) No. 1 — Body / 10 V, or more**



## 3. CHECK CONTINUITY OF HEADLIGHT ALARM RELAY.

- 1) Remove headlight alarm relay.
- 2) Check continuity between terminals No. 1 and No. 2 of headlight alarm relay.



## 4. CHECK HARNESS CONNECTOR BETWEEN HEADLIGHT ALARM RELAY AND SECURITY CONTROL MODULE.

- 1) Disconnect connectors of headlight alarm relay and security control module.
- 2) Measure resistance of harness connector between headlight alarm relay and security control module.

**Connector & terminal / Specified resistance:**  
**(B58) No. 2 — (B93) No. 12 / 10  $\Omega$ , max.**

## 5. CHECK HEADLIGHT ALARM RELAY.

Refer to 6-2 [W22B2] for inspection of headlight alarm relay.