

B: INSPECTION


Check that connector is connected correctly and that connector terminal sliding resistance is correct.

C: INSTALLATION

To install, reverse the removal procedure.

17. G Sensor for ABS System (ABS 5.3 Type)**A: REMOVAL AND INSTALLATION**


- 1) Turn ignition switch to OFF.
- 2) Remove console box. <Ref. to 5-4 [W1A0].>
- 3) Disconnect connector from G sensor.



- 4) Remove G sensor from body.
- 5) To install, reverse the removal procedure.

CAUTION:

Do not drop or bump G sensor.

**B: INSPECTION****1. USING CIRCUIT TESTER**

- 1) Turn ignition switch to OFF.
- 2) Remove G sensor from vehicle.
- 3) Connect connector to G sensor.
- 4) Turn ignition switch to ON.
- 5) Measure voltage between G sensor connector terminals.



: Connector & terminal

(P9) No. 2 (+) — No. 1 (—)


Is voltage 2.3 ± 0.2 V when G sensor is horizontal?



: Go to next




: Replace G sensor.



CHECK : **Connector & terminal**
(P9) No. 2 (+) — No. 1 (–)
Is voltage 3.9 ± 0.2 V when G sensor is inclined forwards to 90° ?

YES : Go to next **CHECK** .
NO : Replace G sensor.




CHECK : **Connector & terminal**
(P9) No. 2 (+) — No. 1 (–)
Is voltage 0.7 ± 0.2 V when G sensor is inclined backwards to 90° ?

YES : G sensor is normal.
NO : Replace G sensor.

2. USING SELECT MONITOR

- 1) Turn ignition switch to OFF.
- 2) Connect select monitor connector to data link connector.
- 3) Turn select monitor into ABS mode.




- 4) Press **[F]**, **[1]** and **[0]** on the select monitor.
- 5) Rear the select monitor display.

CHECK : **Is the indicated reading 2.3 ± 0.2 V when the vehicle is in horizontal position?**

YES : Go to next step 6).
NO : Replace G sensor.


- 6) Remove console box.
- 7) Remove G sensor from vehicle. (Do not disconnect connector.)



- 8) Read the select monitor display.

CHECK : **Is the indicated reading 3.9 ± 0.2 V when G sensor is inclined forwards to 90° ?**

YES : Go to next **CHECK** .
NO : Replace G sensor.



- CHECK** : Is the indicated reading 0.7 ± 0.2 V when G sensor is inclined backwards to 90° ?
- YES** : G sensor is normal.
- NO** : Replace G sensor.