


9. Rear Strut

A: REMOVAL



- ① Strut mount cap
- ② Self-locking nut
- ③ Strut mount
- ④ Rubber seat upper
- ⑤ Dust cover


- ⑥ Coil spring
- ⑦ Helper
- ⑧ Rubber seat lower
- ⑨ Damper strut

Tightening torque: N·m (kg-m, ft-lb)

T1: 20±6 (2.0±0.6, 14.5±4.3)


T2: 59±10 (6.0±1.0, 43±7)

T3: 196⁺³⁹₋₁₀ (20.0^{+4.0}_{-1.0}, 145⁺²⁹₋₇)



1) Depress brake pedal and secure it in that position using a wooden block, etc.

2) Remove rear seat cushion and backrest. (Sedan)




3) Remove strut cap of rear quarter trim. (Wagon)


4) Loosen rear wheel nuts.

5) Jack-up vehicle, support it with safety stands (rigid racks) and remove rear wheels.

6) Remove brake hose clip.



- 7) Models equipped with rear disc brakes:
Remove union bolt from brake caliper.
- 8) Models equipped with rear drum brakes:
Disconnect brake hose from brake pipe from strut, and disconnect brake pipe from drum brake.



- 9) Remove bolts which secure rear strut to housing.
- 10) Remove nuts securing strut mount to body.
- 11) Remove strut mount cap.

B: DISASSEMBLY

For disassembly of rear strut, refer to procedures outlined under front strut as a guide.

<Ref. to 4-1 [W4B0].>

C: INSPECTION


Refer to Front Strut [W4C0] as a guide for inspection procedures.

D: ASSEMBLY

Refer to Front Strut [W4D0] as a guide for assembly procedures.

CAUTION:

- Install rear strut with “FWD” or “4WD” mark on strut mount facing outside of vehicle body.
- Insert the protrusion of lower rubber seat into the strut spring seat hole.



E: INSTALLATION

- 1) Install strut mount cap.
- 2) Tighten self-locking nut used to secure strut mount to vehicle body.

CAUTION:

Use a new self-locking nut.

NOTE:

Tighten strut mount and cap as a unit.

Tightening torque:

20 ± 6 N·m (2.0 ± 0.6 kg-m, 14.5 ± 4.3 ft-lb)

- 3) Tighten bolts securing rear strut to housing.

Tightening torque:

196^{+39}_{-10} N·m ($20.0^{+4.0}_{-1.0}$ kg-m, 145^{+29}_{-7} ft-lb)

CAUTION:

Use a new self-locking nut.

- 4) Models with rear disc brakes:
Tighten brake hose union bolt on brake caliper.

Tightening torque:

18 ± 3 N·m (1.8 ± 0.3 kg-m, 13.0 ± 2.2 ft-lb)

- Models with rear drum brakes:
Connect brake hose to brake pipe.

Tightening torque:

15^{+3}_{-2} N·m ($1.5^{+0.3}_{-0.2}$ kg-m, $10.8^{+2.2}_{-1.4}$ ft-lb)

- 5) Insert brake hose clip between brake hose and lower side of strut.

CAUTION:

- Check that hose clip is positioned properly.
- Check brake hose for twisting, or excessive tension.
- Models equipped with A.B.S.:

Do not subject A.B.S. sensor harness to excessive tension.

- 6) Be sure to bleed air from brake system.
- 7) Lower vehicle and tighten wheel nut.

Tightening torque:

88 ± 10 N·m (9 ± 1 kg-m, 65 ± 7 ft-lb)

- 8) Sedan:
Install rear seat backrest and rear seat cushion.

Wagon:

Install strut cap of rear quarter trim.

NOTE:

Check wheel alignment and adjust if necessary.