


7. Hill Holder



① PHV cable	⑦ Adjusting nut
② Clamp	⑧ Snap pin
③ Bracket A	⑨ Clip
④ Pin	⑩ PHV (Pressure hold valve)
⑤ Bushing	⑪ Bracket
⑥ Release fork	

Tightening torque: N·m (kg·m, ft·lb)
T1: 3.4±1.0 (0.35±0.10, 2.5±0.7)
T2: 18±5 (1.8±0.5, 13.0±3.6)
T3: 33±4 (3.4±0.4, 24.6±2.9)