


1. Front Hood and Hood Lock



① Front hood	⑧ Front hood stay
② Hinge (RH, LH)	⑨ Front hood seal CTR
③ Front hood seal	⑩ Hood duct (Outback and GT model)
④ Lever ASSY	⑪ Hood inner (Outback and GT model)
⑤ Cable	
⑥ Striker	
⑦ Hood lock ASSY	

Tightening torque: N·m (kg-m, ft-lb)

T1: 14±9 (1.4±0.9, 10.1±6.5)

T2: 32±1 (3.3±0.1, 23.9±0.7)