


1. Front Seat



G5M0522

① Headrest free bushing	⑩ Connect wire
② Headrest lock bushing	⑪ Outer slide rail ASSY
③ Headrest ASSY	⑫ Front cushion frame ASSY
④ Front backrest frame ASSY	⑬ Cushion ASSY
⑤ Protector	⑭ Reclining lever
⑥ Cover (Bolt) (outer)	⑮ Hinge spring cover
⑦ Cover (Bolt) (inner)	⑯ Reclining hinge ASSY
⑧ Inner belt ASSY	⑰ Backrest ASSY
⑨ Inner slide rail ASSY	⑱ Hinge cover

⑲ Tilt lever cover
⑳ Tilt lever ASSY

Tightening torque: N·m (kg·m, ft·lb)**T1: 23±5 (2.3±0.5, 16.6±3.6)****T2: 29±7 (3.0±0.7, 21.7±5.1)****T3: 52±10 (5.3±1.0, 38±7)**